



Installation of SM 70 through table shock mount

- 1) Drill a 51mm (2.01") diameter hole in the surface on which the SM 70 is to be mounted.
- 2) Centre the SM 70 on the surface above the hole.
- 3) Mark on the surface the location of the three screw holes in the SM 70, remove SM 70, and drill starter holes in the three marked places.
- 4) Fit the SM 70 into the hole and fasten to the surface using the self tap screws provided.