

Microphone stand with fully programmable membrane switch, giving the option between push to talk, push to mute or latching without the need to change dip switches. Fitted with Mini XLR connector input to accommodate slim line Series microphones and LED indicator to identify microphone status.



SPECIFICATIONS

| Switching: | Touch Pad Fully Programmable for PTT, PTM & Latching | | | |
|-------------------------|--|--|--|--|
| Indication: | Red LED | | | |
| Input: | 3Pin Mini XLR with built in Phantom Power Module. PIN 1 = Phase - PIN 2 = Phase + PIN 3 = Ground | | | |
| Output: | 5Pin XLR PIN 1 = Ground PIN 2 = Control Input (activated in program 4 option 2) PIN 3 = PHASE – PIN 4 = Switch Out (Logic low when switch pressed) PIN 5 = PHASE + | | | |
| Power | 48V Phantom Power | | | |
| Requirements Finish: | satin black | | | |
| Options: | Microphones: C3100 C310-R C312-SR C313- SR C314-SR | | | |
| Dimensions: | Length Width Height | | | |
| | 120mm 100mm 32mm (4.8") (3.94") (1.26") With XLR: 600mm (2.36") | | | |
| Weight: | 636g (22.4oz) | | | |

Programming options

| Program mode (Press number of times for selection required) | Description | Option 1 (Press Once) | Option 2 (Press Twice) |
|---|---------------------|--|--|
| 1 | Switch Type | Momentary | Latching |
| 2 | Switch Action | PTT (Normally Off) | PTM (Normally On) |
| 3 | Activation Tone | Off | On |
| 4 | Control Mute | On—Microphone muted at base. LED indicates live microphone | OffMicrophone muted externally. LED indicates Logic low |
| 5 | Switchable 10dB Pad | 0dB | -10dB |
| 6 | Bass roll Off | 100Hz | 400Hz |

Switch operating Instructions

1) Apply power with switch pressed.

'RF Friendly' technology offering immunity from GSM radio frequency interference

- 2) Unit gives regular flash for 2 seconds on LED to show set up mode entered.
- 3) Press switch the number of times of the programming mode you wish to check or change. The interval between key presses must be less than 1 second.
- 4) After the mode has been selected the LED will flash the number of times of the option currently set.
- 5) Press the switch the number of times of the option required. The interval between key presses must be less than 1 second.
- 6) The LED will flash the number of times of the option already set.
- 7) The unit then returns to stage 2, ready for setting more options.
- 8) The unit will return to normal operation after 5 seconds if the key is not pressed.

© Clockaudio. All rights reserved. Product specifications subject to change without notification.